



INSTALLATION INSTRUCTIONS

*Thank
you!*

Thank you for choosing Groove Grids Bumpers for your collection.

Please follow the instructions on this page to ensure long and effective use.

An installation video is available on YouTube – Scan the QR code to view now.



1. Always test fit the left and right sections of each bumper before removing the adhesive backing. Make sure you are happy with the final record position before proceeding to step 2.
2. Ensure surfaces to which tape is to be applied are clean, sound and dry. Non-porous surfaces like IKEA KALLAX shelves must be de-greased with the included alcohol wipe and allowed to dry before application. Press item to be bonded firmly into place with even pressure. A secure bond will be formed immediately however full bond strength will be achieved after 48 hours.

The adhesive tape is marketed by Ever Build Mammoth as follows:

- Strong initial bond strength
- Bonds almost any material
- Weatherproof
- Moisture-resistant
- For indoor and outdoor use
- Initial tack 18 N/25 mm
- Shear strength (3 kg static shear) > 800 hours

3. Despite the qualities of the tape, unpredictable environmental factors impact the performance of adhesive over time. For that reason, the Groove Grids Bumpers feature a pre-drilled screw hole and recess for a washer. Whilst not mandatory, it is recommended that you first position and secure the bumpers to your liking using the adhesive before then using the provided 3.5 x 20mm screws and washers to complete the installation.
4. Should you choose to follow the recommended installation advice and strengthen the fixing with the supplied screws, it can be advisable to pre-drill the hole using a suitable bit to prevent splitting.

Once again, thank you for your custom and support.

Please leave honest feedback and join the community on your preferred social media platform below.

Kit contents:

Bumper – Left Sections
Alcohol Wipes

Bumper – Right Sections
Washers

Mammoth Adhesive Strips
Screws

